

## Instructions for Extensions 4938 / 4958 / 5015 / 5016

Extension 4938 for use with gate models: 4928, 4934

Extension 4958 for use with gate model: 4954S


Extension 5015 for use with gate model: 5011

Extension 5016 for use with gate model: 5012

### IMPORTANT: PLEASE KEEP FOR FUTURE REFERENCE!


For helpful tips and instructions, please visit our website: [www.northstatesind.com](http://www.northstatesind.com)  
or contact our Customer Care department via email: [CustomerService@northstatesind.com](mailto:CustomerService@northstatesind.com)  
Phone: (763) 486-1754 or Toll Free: (800) 848-8421

#### Step 1:




Remove one vertical bar by twisting clockwise then pushing down while pulling out.

#### Step 2:



Separate the two panels.

#### Step 3:




Next, remove the vertical bar at the end of the extension panel (as instructed in step 1).

#### Step 4:



To connect the end sections, lift one panel allowing the upper and lower hinge housings to slip into place in the mating panel.

#### Step 5:



Insert the vertical bar into recess of lower hinge mount. Press down and slide it into the upper hinge.

#### Step 6:



Adjust the sections as needed. Tighten each top hinge counter-clockwise to lock in place.

Distributed exclusively in the United States by  
North States Industries, Inc.  
5455 Highway 169 N  
Plymouth, MN 55442  
[www.northstatesind.com](http://www.northstatesind.com)

Manufactured in China