



NO TOOLS NEEDED


Multi-functional.
Works on glass
or wood surfaces.

Simple slide and
release motion
activates the
wings to lock.

Soft white wing
design blends
seamlessly with
any home décor.

INSTALLATION METHOD

- 1 Adult Installation Required.** Clean and dry surface of sliding door or window.
- Prior to adhering, be sure to select a location that is out of reach of the child. Ensure that the door/window you wish to install the Sliding Door & Window Lock is in the closed position.
- Remove VHB® adhesive backing and press Sliding Door & Window Lock 3-4 inches from door/window frame for 1 minute. For best results, allow adhesive to set for 24 hours prior to use.



VHB is a registered trademark of 3M Company.

OPERATION

Slide center disc to activate wings to lock.
To release, press wings down and slide center disc.

REMOVAL TIP

Easily remove product by applying heat (hairdryer) for about one minute. Gently pull product away from surface.

CAUTION: This product will not necessarily prevent all accidents and is only a deterrent. It is not a substitute for proper adult supervision. Stop using when child becomes old enough to defeat it. Regularly check for wear and correct positioning. DO NOT use product if damaged or broken. FOR INDOOR HOME USE ONLY.

WARNING: Any damage to the property during installation or removal of this product is the sole responsibility of the end user.

PRECAUCIÓN: Este producto no necesariamente evitará todos los accidentes y solo es una medida disuasoria. No es un sustituto de la adecuada supervisión por adultos. Deje de usarlo cuando el niño llegue a estar lo suficientemente grande para vencerlo. Revise regularmente por uso y posición correcta. NO use el producto si está dañado o quebrado. SOLO PARA USO EN EL INTERIOR DE LA CASA.

ADVERTENCIA: Cualquier daño ocasionado a la propiedad durante la instalación de este producto es la exclusiva responsabilidad del usuario final.

MISE EN GARDE: Ce produit ne préviendra pas nécessairement tous les accidents et n'aura qu'un effet dissuasif. Ce produit ne remplace pas la surveillance appropriée par un adulte. Cessez de l'utiliser quand l'enfant devient assez âgé pour en comprendre le fonctionnement. Vérifiez régulièrement l'usure et le positionnement correct. N'utilisez PAS le produit s'il est endommagé ou cassé. POUR USAGE DOMESTIQUE INTÉRIEUR SEULEMENT.

AVERTISSEMENT: L'utilisateur final est entièrement responsable de tout dommage matériel causé durant l'installation ou le retrait de ce produit.



0 26107 06152 2

MADE IN CHINA

DISTRIBUTED IN THE USA BY:
NORTH STATES INDUSTRIES, INC.
5455 HIGHWAY 169 N.
PLYMOUTH, MN 55442
WWW.NORTHSTATESIND.COM

