

Instructions for Extension 8650

For use with yard models: 8657, 8668, 8669, 8761, 8800, 8807

Important: Please keep for further reference.

For helpful tips and instructions, please visit our website: www.northstatesind.com or contact our Customer Care department via email: CustomerService@northstatesind.com
Phone (763) 486-1754 or Toll Free: (800) 848-8421

NOTE: You must always use an even number of panels to connect the Superyard.

The maximum number of panels that can be connected together is 8.

Installation and Operation

Step 1: If your Petyard is already connected together, follow these steps to disconnect your Petyard. Select one of the joints where the panel pushes down (panel 1) See Figure 1. Gently press down on panel 1 while lifting slightly on panel 2. This will enable you to slide pin "C" free of cylinder D See Figure 2. Lift up on panel 1 until opening "A" is free of pin "B" See Figure 3.

Step 2: Carefully unfold the Petyard to the proper set-up configuration as shown.

Step 3: Begin connecting your extension to your enclosure by lifting up on panel 1 and setting the opening "A" over Pin "B" located on panel 2 See figure 4.

Step 4: Now locate the slot on the lower end of cylinder "D". This slot tapers to an opening that accommodates pin "C" See figure 5. Gently press down on panel 1 while aligning pin "C" with the end of the slot in cylinder "D" while maintaining downward pressure on panel 1, lift slightly on panel 2, and slide pin "C" through the slot and into the opening.

Step 5: Connect the other side of the extension by following steps 3 & 4.

Pet Door Operation


Your enclosure comes from the factory with the pet door in the "LOCKED" POSITION See figure 6.


TO UNLOCK


Squeeze and twist the front center knob located below the pet door. As you twist, the knob will line up with the arrows on the right or left sides of the knob. The pet door will move freely in both directions for your pet to pass through.


TO LOCK


Squeeze and twist the front center knob located below the pet door. As you twist, the knob will be in the upright position, keeping the door securely locked.











!\ WARNING

Make certain that the pet door is securely locked in the closed position if using with a child 6 to 24 months.