

x4 DOOR KNOB COVERS

Prevents child from opening doors. Universal fit over most standard door knobs.



INSTALLATION METHOD

- 1 Separate halves of Door Knob Cover and place around door knob.
- 2 Reassemble Door Knob Cover by aligning all tabs and snap in place. Door Knob Cover should spin freely.



OPERATION

To open door, simply press both side buttons on the Door Knob Cover and turn knob.






x4 SLIDING CABINET LOCKS

Prevents child from opening cabinets. Universal fit on side-by-side cabinets with knobs or D-shaped handles.



INSTALLATION METHOD

- 1 Open lock by simultaneously pressing the side release buttons. Slide locking base off the locking arm.
- 2 Place locking arm around cabinet knobs or through handles.
- 3 Slide the locking base back onto the locking arm so the arrows align with the locks.
Note: If the locks on the locking base are not properly aligned with the arrows on the locking arm, the locking latch will just slide off without having to depress the side gray buttons and will not be secure.



OPERATION

Press the side release buttons simultaneously and slide off.

x4 GEL CORNER PROTECTORS

Protects child from bumps and bruises around sharp corners. Universal fit. Cushion furniture such as tables, desks, nightstands, cabinets. Also great for kitchen countertops.



INSTALLATION METHOD

- 1 Clean and dry surface of furniture or counter.
- 2 Attach the adhesive to all three inside edges of Gel Corner Protector.
- 3 Remove adhesive backing and press firmly in place. For best results, allow adhesive to set for 24 hours prior to use.



REMOVAL TIP

Easily remove product by applying heat (hairdryer) for about one minute. Gently pull product away from surface. Clean with soap suitable for your surface.

x1 PREMIUM PINCH PROTECTOR

Prevents child from closing doors on tiny fingers. Universal fit on most doors.



INSTALLATION METHOD

- 1 Place Pinch Protector on outer edge of door out of reach of child.
- 2 May also be placed on top edge of door, no less than 6 inches from outer edge.
- 3 Regularly check the Pinch Protector for wear and replace if necessary.






x18 DRAWER & CABINET TAB LATCHES

Protects child from dangerous items in drawers and cabinets. Multi-functional. Works on the top or side of most drawers and cabinets with even surfaces.



INSTALLATION METHOD

- 1 Clean and dry inside surface of drawer or cabinet.
- 2 Using adhesive, position the catch approximately 1" from the inside top edge of the drawer or cabinet. Align the Tab Latch to engage with the catch. Once properly positioned, secure both the catch and Tab Latch into place with the screws provided.



OPERATION

To use, open drawer or cabinet slightly and press the Tab Latch down in order for it to clear the catch and fully open. When closing the drawer or cabinet, the Tab Latch will engage automatically. To disengage, press the Tab Latch completely down into the base until it 'clicks' enabling the drawer or cabinet to open/close freely.

x34 PLUG PROTECTORS

Helps protect child from electrical hazards. Fits all 2 and 3 pronged outlets.



INSTALLATION METHOD

- 1 Simply insert the Plug Protector into any open outlet.
- 2 Push firmly into place.



REMOVAL METHOD

Slide your fingernail under the edge of the Plug Protector and pull.

CAUTION: These products will not necessarily prevent all accidents and are only a deterrent. They are not a substitute for proper adult supervision. Stop using when child becomes old enough to defeat them. Regularly check for wear and correct positioning. Adhesive may remove finish from some surfaces so please test on small area first. DO NOT use product if damaged or broken. FOR INDOOR HOME USE ONLY.

WARNING: Adult installation required. Do not use these products to guard against toxic and dangerous substances or objects. These dangerous items should always be kept "high-up" or placed in an area completely inaccessible to the child. These products are not toys. DO NOT allow children to play with them. Any damage to the property during installation or removal of this product is the sole responsibility of the end user.

PRECAUCIÓN: Estos productos no necesariamente evitarán todos los accidentes y solo son una medida disuasoria. No hay un sustituto de la adecuada supervisión por adultos. Deje de usarlo cuando el niño llegue a estar lo suficientemente grande para vencerlos. Revise regularmente por uso y posición correcta. El adhesivo puede retirar el acabado de algunas superficies así que pruebe primero en un área pequeña. NO use el producto si está dañado o quebrado. SOLO PARA USO EN EL INTERIOR DE LA CASA.

ADVERTENCIA: Se necesita que un adulto lo instale. No use estos productos como protección contra sustancias y objetos tóxicos y peligrosos. Estos artículos peligrosos siempre se deben mantener "a gran altura" o colocarse en un área completamente inaccesible para el niño. Estos productos no son juguetes. NO permita que los niños jueguen con él o lo mastiquen. Cualquier daño ocasionado a la propiedad durante la instalación de este producto es la exclusiva responsabilidad del usuario final.

MISE EN GARDE: Ce produit ne préviendra pas nécessairement tous les accidents et n'aura qu'un effet dissuasif. Ces produits ne remplacent pas la surveillance appropriée par un adulte. Cessez de les utiliser quand l'enfant devient assez âgé pour en comprendre le fonctionnement. Vérifiez régulièrement l'usure et le positionnement correct. L'adhésif peut enlever le fini de certaines surfaces, veuillez donc commencer par tester sur une petite surface. N'utilisez PAS le produit s'il est endommagé ou cassé. POUR USAGE DOMESTIQUE INTÉRIEUR SEULEMENT.

AVERTISSEMENT: Installation par un adulte requise. N'utilisez pas ces produits pour vous protéger contre les substances ou objets toxiques et dangereux. Ces objets dangereux doivent toujours être conservés « en hauteur » ou placés dans un endroit totalement inaccessible pour l'enfant. Ces produits ne sont pas des jouets. NE laissez PAS les enfants jouer avec les produits ou les mordre. L'utilisateur final est entièrement responsable de tout dommage matériel causé durant l'installation ou le retrait de ce produit.



MADE IN CHINA

DISTRIBUTED IN THE USA BY:
NORTH STATES INDUSTRIES, INC.
5455 HIGHWAY 169 N.
PLYMOUTH, MN 55442
WWW.NORTHSTATESIND.COM

